

# **CT3515 10W Rechargeable Portable LED Work Light**

## **FAQS**

### **Power Switch**

The red power switch is located on the rear of the light. Press once for high, press again for off. The next press of the switch will turn on the low setting. Press once more for off. The sequence is as follows.

High – Off – Low – Off

### **Battery Charge Level Indicator**

The charge level indicator is located on the rear of the light, under the protective cover. Open the protective cover and press the white button. The indicators will illuminate for three seconds.

- 3 Green lights: 70% - 100% charge remaining
- 2 Green Lights: 40% - 69% charge remaining
- 1 Green light: 1% - 39% charge remaining

### **Charging the CT3515**

Using the charger provided, connect the power cable into the charging port, and plug the charging adapter into a wall outlet or other power source. Once connected, the charging indicator on the adapter will turn red to indicate that the light is charging. Once the light is fully charged (3-5 hours), the adapter indicator will turn green.

The CT3515 LED Work Light can also be used with continuous A/C power, simply connect the power cable as described above and plug it into any A/C power source. (Using the light with A/C power simultaneously charges the batteries.)

Use only the provided A/C charger when charging this light. Use of an incorrect charger will void any warranty and may damage the light. Replacement chargers may be obtained by contacting: 1-800-522-7947 ext 228 inside the USA or 1-607-467-2866 outside the USA 8am to 5pm EST Monday through Friday. You may also contact [warranty@ezred.com](mailto:warranty@ezred.com)

### **USB Output Charge Port**

The USB port is compatible with any outbound USB cable and most devices. \*(Outbound cable not included with CT3515)

To begin outbound charging, first plug the USB end of the cable into the port, and then plug the other end into your device. Press and hold the Battery Charge Level Indicator Button for three seconds to engage outbound power. When in use, the Battery Charge Level Indicator lights will illuminate, displaying the amount of charge the light battery has reserved.

In rare instances attempting to charge certain devices may cause the CT3515 battery to shut off in order to prevent overdraw. If this should occur, disconnect the out bound USB cord and plug the A/C charger into the light. This will reset the battery. You may attempt to charge the device in question again, but if it repeatedly causes overdraw prevention shut off, that device is not compatible with the outbound charge feature.

## **Care & Cleaning**

Allow the work light to cool down before cleaning. Once the work light is cool to the touch, clean it with a soft cloth and non-abrasive cleaner. Store the light in a safe and dry location.

## **Troubleshooting**

If the work light does not work: Press/hold down the white button to determine the battery life. If fewer than three green LED indicators display, charge the light. Be sure to cycle the power button as well. For additional troubleshooting information, call the Warranty Department at 1-800-522-7947 ext 228 inside the USA or 1-607-467-2866 outside the USA 8am to 5pm EST Monday through Friday. You may also contact [warranty@ezred.com](mailto:warranty@ezred.com)